


User Guide (For HAN-40T & HAN-50T)

HAN-T

Handy Screen



Important Notes:

All screens are thoroughly inspected and fully tested operational in factory.
 We accept no liability whatsoever for any losses due to improper operation, or any unauthorized alternation.
 All trademarks contained in this installation guide are the property of their respective owners.

To Setup Screen:

1. Open all four leg supports. 90° to casing. Leg supports snap into correct position.
2. Place closed unit with carry handle on left side. Hold left side of casing in right hand. Depress two buttons on front and back of housing (clearly marked) with thumb and index finger..
3. Open screen slowly to desired width.
4. Place on flat and stable table.
5. Position for data projection viewing.

To Keep Screen:

1. Repeat instruction No. 2. Casing will automatically snap closed.
2. Close gently. No great force is required.
3. Close leg supports by squeezing them.

Important Remarks:

- * To close leg supports, squeeze legs together at base of housing. Fold up to closed position. Legs will automatically snap into position.
- * Do not allow screen to be exposed to direct sunlight as it could fade white matte screen viewing surface.